Meru NETWORKS®

# IDENTITY MANAGER INTEGRATION WITH CISCO WLC

SECTION B

# WHAT YOU WILL LEARN

- Configure an SSID for Web Authentication
- Add IDM as the RADIUS Server
- Set IDM as the external web portal
- Configure IDM for Cisco Wireless LAN Controllers

# LOGIN TO THE WEB CONSOLE






MERU NETWORKS®

# ADD IDM AS A RADIUS AUTH SERVER




eRu NETWORKS®

# ADD IDM AS A RADIUS ACCT SERVER



# CREATE A PRE-AUTHENTICATION ACL






MERU NETWORKS®

# ADD A DESTINATION RULE



# ADD A SOURCE RULE



# ADD A NEW SSID






MERU NETWORKS®

# SET LAYER 2 TO BE AN OPEN NETWORK






MERU NETWORKS®

# SET LAYER 3 TO USE IDM



# IDM URLs

- The URLs that the controller needs to redirect the user to are on IDM.
- The initial redirection should go to https://[IDM-Name-or-IP]/portal/[Controller-IP]
  - The IDM-Name-or-IP should match the SSL certificate common name on IDM
  - The Controller-IP is the IP address of the controller
  - Don’t enter the [] brackets

# SET AAA SERVERS




Meru NETWORKS®

# SET AAA SERVERS




MERU NETWORKS®

# SET WLAN TO ENABLED



# ADD THE CONTROLLER TO IDM




# Thank you